

Acro 5-Bolt Quick-Change Inverted Gear Ratio Chart

For use with transmission-driven setups.

Ultimate Ratio	Lower Gear #	Upper Gear #	Ultimate Ratio	Lower Gear #	Upper Gear #	Ultimate Ratio	Lower Gear #	Upper Gear #
5.875	33	33	4.287	37s	27s	3.077	42s	22s
5.697	33	32s	4.174	38	27s	3.006	43	22s
5.529	34	32	4.067	39	27	2.938	44	22
5.519	33s	31s	4.020	38s	26s	2.869	43s	21s
5.357	34	31s	3.917	39	26s	2.804	44	21s
5.204	35	31	3.819	40	26	2.742	45	21
5.184	34s	30s	3.766	39s	25s	2.670	44s	20s
5.036	35	30s	3.672	40	25s	2.611	45	20s
4.896	36	30	3.582	41	25	2.554	46	20
4.868	35s	29s	3.525	40s	24s	2.481	45s	19s
4.733	36	29s	3.439	41	24s	2.427	46	19s
4.605	37	29	3.357	42	24	2.375	47	19
4.569	36s	28s	3.296	41s	23s	2.299	46s	18s
4.446	37	28s	3.217	42	23s	2.250	47	18s
4.329	38	28	3.142	43	23	2.203	48	18